



GENERAL NOTES:

- BACKSIDE OF MOULDING TO BE HOLLOW
- PL PREMIUM ADHESIVE MUST BE USED ON ALL BEDDING/BUTT JOINTS



© 2006, Spectis Moulders Inc. All rights reserved. This document may not be used or duplicate without prior consent.

P.O. BOX 970
100 CEDAR DRIVE
NIVERVILLE, MANITOBA
CANADA R0A 1E0

PHONE: 204-388-6700
PHONE: 800-685-9981
FAX: 204-388-6710

BOX 479
PEMBINA,
NORTH DAKOTA
58271-0479
U.S.A

- GENERAL NOTES:
1. ALL PRODUCTS ARE DRAWN FOR PRESENTATION PURPOSES, ONLY IMAGE MAY VARY SLIGHTLY FROM ACTUAL PART
 2. DRAWING INTENT IS TO INDICATE GENERAL ARRANGEMENT, DESIGN AND INTENT OF WORK IS PARTLY DIAGRAMATIC.
 3. SPECTIS RESERVES THE RIGHT TO CHANGE ANY PRODUCT DESIGN WITHOUT NOTICE.

CUSTOMER NAME:			PART:
ARCHITECTURAL ELEMENTS			MD#03
REFERENCE:			SHEET:
PO# 3962			1 OF 1
DRAWN BY:	DATE:	SCALE:	REV:
JE	07/01/25	$\frac{3}{16} = 1"$	